

# GE Pre-lit Christmas trees

## Easy to Assemble

1. Empty tree carton, unwrap all parts.



2. Set tree stand.



3. Insert bottom section into tree stand.



4. Tighten screw to secure bottom section in the tree stand.




5. Un-tie RED twist-tie to release branch panels.



**DO NOT** plug in and turn lights on until assembly is completed.



6. Insert mid section.



7. Insert plug from extension cord of mid section into extension cord outlet of the bottom section attached to the pole of the bottom section.



Make sure all plugs are firmly connected.

8. Fluff branch panels of bottom section.



9. Un-tie RED twist-tie to release mid section branch panels.



10. Fluff branch panels of mid section.



11. Fluff the tree top branch panels before putting it on top of the tree.



12. Insert tree top into mid section.



**DO NOT** insert tree top without fluffing first.



13. Insert plug from extension cord of tree top into extension cord outlet of the mid section attached to the pole of the mid section.



14. Fluff and adjust branch panels to make tree look fuller.



15. Insert main plug attached to the pedal switch into a electrical wall outlet or a extension cord. Press the switch to turn lights on.



Pedal Switch

Tree assembly completed and branch panels are fully shaped.



Correct

Branch panels are **NOT** fully shaped.



Incorrect

Fully shaped and lit tree.



Correct

Branch panels are **NOT** fully shaped.



Incorrect